

## DuroBase

### Installation Instructions

- Install wall base straight, level, and tight to the substrate with adhesive or appropriate fasteners.
- At corners, provide mitered cuts.
- Use maximum lengths to minimize joints. Provide scarf joints between pieces.
- Caulk any gaps as necessary

### Important

1. Acclimate materials to the installation environment for 24 hours prior to installation. Maintain a temperature controlled environment during and after installation.
2. To cut the material, use a chop saw with fine-tooth blade.

**DISCLAIMER:** Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any problems caused by errors in installation. The manufacturer of this product shall not be held responsible for installation actions taken or not taken. There are many details of installation that are assumed to be general construction knowledge to experienced installers; which are not included in these instructions. These installation guidelines are intended to be strictly recommendations and are not to serve as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner and architect. Protek Systems, Inc. does not accept any responsibility for job failure resulting from or associated with improper site environmental conditions and installation failure due to expansion contraction issues.