## Kick Plate


## **Field Measurement**

- Protek kick plates are manufactured in accordance with field dimensions provided by the customer. All kick plates are pre-cut, pre-drilled, and formed at the factory and should require no further modification. It is recommended to allow 1 1/4-inch to 1 1/2-inch for door stops when measuring the width of the door.

## Installation Instructions

- <u>Adhesive installation</u> - Dry fit the kick plate to the door to ensure a proper fit. Place beads of adhesive 2" away from the perimeter edges and across the width of the material every 8-12 inches. Press the kick plates in place by hand, and then run a heavy pressure roller back and forth across the kick plate to make sure there is strong adhesion between the door and the kick plate. Allow 24-48 hours for the adhesive to cure. Additional bracing can be used to prevent movement once the kick plates are in place.

> <u>Screw-On installation</u> - Dry fit the kick plate to the door and mark the mounting hole locations on the door. Drill pilot holes into the door, then fasten the kick plate to the door with the appropriate hardware.



**DISCLAIMER:** Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any problems caused by errors in installation. The manufacturer of this product shall not be held responsible for installation actions taken or not taken. There are many details of installation that are assumed to be general construction knowledge to experienced installers; which are not included in these instructions. These installation guidelines are intended to be strictly recommendations and are not to serve as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner and architect. Protek Systems, Inc. does not accept any responsibility for job failure resulting from or associated with improper site environmental conditions and installation failure due to expansion contraction issues.

## Installation